



G-JR Chemical Injection Pump

Electrically Operated Chemical Injection Pumps



PROVEN QUALITY. LEADING TECHNOLOGY.

G-JR Chemical Injection Pump

Features and Benefits

The Graco G-JR is an ideal chemical injection pumping solution that has been engineered to offer reliable chemical dosing at a low cost.

Built from the same quality standards as other Graco chemical injection pumps, the G-JR is simple to operate, easy to service and offers the lowest up front cost. Offered in DC solar or AC electric, the pumps come standard with the Harrier™ EZ-JR controller which offers a similar set of features as the current Harrier EZ controller.

Simple Design

- Single plunger size
- One seal material option
- UHMWPE seal
- Ideal for chemicals with pH levels between 4-9

Graco Quality

- Designed to strict ISO safety standards
- Proven technology
- Low friction drivetrain for better electrical efficiency

Harrier EZ-JR

- Controls injection rates via time mode
- Optional temperature based dosing
- Battery voltage display
- Built in low voltage disconnect
- Pump priming mode

Easy to Service

- Easily replace pump in less than 10 minutes
- Minimal tools required
- Modular solar package



Harrier EZ-JR



Flow & Pressure

Part No.	Voltage	Maximum Flow Rate	Maximum Working Pressure
25T650	12 VDC	32 QPD (30.3 LPD)	2000 PSI (137 Bar)
25T651	120 VAC		

Technical Data

G-JR Chemical Injection Pump		
	US	Metric
Maximum fluid working pressure	2000 psi (13.7 MPa, 137 bar)	
Input Voltage	12 VDC	
	115 VAC	
Maximum Input Current	16 A @ 12 VDC	
	3.0 A @ 115 VAC Single Phase	
Environmental temperature range, ordinary location	-40° – 120°F	-40° – 50°C
Operating Temperature Range	0° – 100°F	-18° – 38°C
Noise (dBa)		
Maximum sound pressure	<70 dBa	
Inlet/Outlet Sizes		
Fluid inlet size	1/4 in. npt(f)	
Fluid outlet size	1/4 in. npt(f)	
Materials of Construction		
Wetted materials on all models	300 Series SST, 400 Series SST, Coated Aluminum, Silicon Nitride, Zirconium Nitride-Coated Tungsten Carbide, UHMWPE,FKM-ETP	

Ordering Information

Part No.	Description
25T650	12 VDC G-JR pump including Harrier EZ-JR controller and temperature probe
25T651	115 VAC G-JR pump including Harrier EZ-JR controller and temperature probe
25T652	Solar package including 12 VDC G-JR pump, battery box, stand and 50W solar panel
25T653	Solar package including 12 VDC G-JR pump, battery box, stand, without solar panel
25T620	Solar kit without panel including battery box and stand
25T564	Solar kit with 50W panel including battery box and stand



ABOUT GRACO

PROVEN QUALITY. LEADING TECHNOLOGY.

Founded in 1926, Graco is a world leader in fluid handling systems and components. Graco products move, measure, control, dispense and apply a wide range of fluids and viscous materials used in vehicle lubrication, commercial and industrial settings.

The company's success is based on its unwavering commitment to technical excellence, world-class manufacturing and unparalleled customer service. Working closely with qualified distributors, Graco offers systems, products and technology that set the quality standard in a wide range of fluid handling solutions. Graco provides equipment for spray finishing, protective coating, paint circulation, lubrication, and dispensing sealants and adhesives, along with power application equipment for the contractor industry. Graco's ongoing investment in fluid management and control will continue to provide innovative solutions to a diverse global market.

GRACO LOCATIONS

MAILING ADDRESS

P.O. Box 1441
Minneapolis, MN 55440-1441
Tel: 612-623-6000
Fax: 612-623-6777

AMERICAS

MINNESOTA

Worldwide Headquarters
Graco Inc.
88-11th Avenue N.E.
Minneapolis, MN 55413

EUROPE

BELGIUM

European Headquarters
Graco BVBA
Industrieterrein-Oude Bunders
Slakweidestraat 31
3630 Maasmechelen,
Belgium
Tel: 32 89 770 700
Fax: 32 89 770 777

ASIA PACIFIC

AUSTRALIA

Graco Australia Pty Ltd.
Suite 17, 2 Enterprise Drive
Bundoora, Victoria 3083
Australia
Tel: 61 3 9467 8558
Fax: 61 3 9467 8559

CHINA

Asia Pacific Headquarters
Shanghai Representative Office
Building 7
1029 Zhongshan Road South
Huangpu District
Shanghai 200011
The People's Republic of China
Tel: 86 21 626 05711
Reception Desk:
86 21 649 50088

INDIA

Graco India Pvt Ltd
Plot No 295, Udyog Vihar Phase-IV
Gurugram - 122015 (Haryana)
India 122001
Tel: 91 124 6610200
Fax: 91 124 6610201

JAPAN

Graco K.K.
1-27-12 Hayabuchi
Tsuzuki-ku
Yokohama City, Japan 2240025
Tel: 81 45 593 7300
Fax: 81 45 593 7301

KOREA

Graco Korea Inc.
438, Samsung 1-ro 1-gil
Hwaseong-si, Gyeonggi-do,
18449
Republic of Korea
Tel: 82 31 476 9400
Fax: 82 31 476 9801

SALES/ DISTRIBUTION/ SERVICE

Call today for product information or to request a demonstration.

866-552-1868 or visit us at www.graco.com/ong

Graco Inc. is registered to I.S. EN ISO 9001

North America
Customer Service
866-552-1868
Fax 877-340-6427